

TO MEASURE GRIP SIZE

Place the gauge opening around the grip and slide the gauge as far up the grip as it will go or until snug. Do not force. Mark the location of the gauge with your fingernail. Remove the gauge and check to see if the marked location is 2" down from the grip cap using the 2" width measurement on the end of the gauge.

When a specific gauge opening matches the 2" measurement down from the grip cap, the correct grip size is read below that opening.

- Note:**
1. Do not slide the grip gauge over the rib remind portion of a grip as this will give an improper reading. Always slide the gauge over the grip so the sides of a opening are touching the right and left side of the grip.
 2. If the grip will not match up with a specific opening at 2" down, then you must interpret the reading as an in-between reading. Example: If the 1/32" oversize men's opening slides too far up the grip or is less than 2" from the grip cap, then the grip size can be interpreted to be in-between or 1/64" oversize men's.
 3. The following chart will cover grip sizes larger than 1/32" men's oversize:



Use this Gauge Opening	Measurement from Grip Cap:	Then Grip Size is:
1/32" Men's Oversize (.930")	2 3/16"	3/64" Men's Oversize (.945")
1/32" Men's Oversize (.930")	2 3/8"	1/16" Men's Oversize (.960")
1/32" Men's Oversize (.930")	2 9/16"	3/32" Men's Oversize (.990")
1/32" Men's Oversize (.930")	2 3/4"	1/8" Men's Oversize (.945")

TO MEASURE SHAFT BUTT SIZE

Slide the gauge opening over the shaft butt to determine its size. If the shaft butt size is determined in this manner and the grip size designation is noted from the mouth of the grip, then the installed grip size can be pre-determined, thus avoiding the usual method of guessing the grip size. See charts below for information.

TO PRODUCE OVERSIZE GRIPS BY INTERCHANGING GRIP SIZE		
Shaft Butt Diameter	Use The Following To Produce Standard Size Grip:	Use The Following To Produce Oversize Grip (approx. 1/64" oversize):
Men's .580"	M58	Not Available — use additional tape
Men's .600"	M60	M58
Men's .620"	M62	M60

If you do not have these grip sizes to produce oversize grips, refer to Tape Wrapping Chart below.

TAPE WRAPPING TO PRODUCE OVERSIZE GRIPS	
Description	*Increase in Diameter
3/4" Masking Tape (Overlap Wrap)	.02"
3/4" Masking Tape (Single Layer Wrap).01"	
2" Double Sided Tape (Single Layer Wrap)	.01"

For converting decimals to fractions, use the following: .015" = 1/64"; .031" = 1/32"; .062" = 1/16"