



RETROFIT ASSEMBLY GUIDE

1

Trim Steel Putter Shaft

Measure OD of putter shaft 5 - 7" above putter head with caliper. Trim steel shaft where the putter shaft transitions at 0.370"



4

Epoxy and Assemble



2

Clean and Prep OD of All-IN Adapter



5

Trim to Desired Playing Length and Grip



3

Clean and Prep ID of Putter Shaft

