



Instructions For:
Shaft Butt Weight Port
Code: **BWP**
12 Individual Shaft Butt Weight Ports
For Steel Shafts

- 1** Insert the Shaft Butt Weight Port into the butt end of the shaft. If the Weight Port will not slide easily into the butt end of the shaft than it may be necessary to lightly sand the four outside corners of the Weight Port to the desire size. It is also possible to drive the Weight Port into the butt end of a steel shaft using a hammer. The four edges of the Weight Port will be shaped to size by a steel shaft.
- 2** Insert desired amount of lead powder, tungsten powder or lead shot into the Weight Port.
- 3** Cover the open end of the Weight Port with masking tape after the desired amount of weight has been added. A cork or epoxy can also be used to seal the Weight Port.
- 4** Proceed with normal gripping procedures.

NOTE:

The inserted Weight Port will extend the length of a golf club by 1/8". To maintain the correct length of the golf club, 1/8" must be removed from the length of the shaft before installing the Weight Port.

4820 Jacksontown Road | P.O. Box 3008 • Newark, Ohio 43058-3008 | Toll Free: 800-848-8358 • FAX: 800-800-3290 | Canada Toll Free: 800-387-5331

e-mail: golfworks@golfworks.com

website: www.golfworks.com

SHIPPING
CODE

L