




Use provided allen wrench and screw to attach both ruler base sections (A & B).
Use additional screws to attach lie angle gauge (C).