

Internal Weighting Instructions

Putters, Woods & Irons

- 1- Modify end of grip with TLP Grip Modifier. See TLP Grip Modifier instructions.
- 2- Make sure the inside of the shaft is clean and dry.
- 3- Screw threaded side of DUAL-TOOL into OPTI-VIBE weight until snug.
- 4- With DUAL-TOOL, insert OPTI-VIBE weight into the "TLP Modified" hole in the butt end of the grip. Make sure to always turn clockwise when inserting, adjusting and removing OPTI-VIBE weights.
- 5- Position OPTI-VIBE weight from 4" to 10" into the shaft. The 4" to 10" space is the area between the lines on the DUAL-TOOL.
- 6- Once desired position of the OPTI-VIBE weight is found, turn DUAL-TOOL counter clockwise to release from OPTI-VIBE weight.
- 7- To remove or change positions of OPTI-VIBE weight, insert threaded end of DUAL-TOOL and turn clockwise until snug and continue to turn clockwise while moving OPTI-VIBE weight.
- 8- To lock OPTI-VIBE weight securely in place use magnetic tip side of DUAL-TOOL to screw in Tour Lock Opti-Lock (locking plug) snug into the top end of OPTI-VIBE weight.

Tip - In some cases, the OPTI-VIBE weights will not be "securely snug" enough to fit in some shafts with larger inside diameters. If this is the case, rap some electrical or adhesive tape around the foam portion of the OPTI-VIBE weight until correct diameter is found and follow the above instructions.