

THE GOLFWORKS®

INSTRUCTIONS FOR: Urethane Vise Pads Code: UVP

Used for both iron and wood head removal, various refinishing steps and virtually any project requiring a club to be secured in a vise in an accessible position.

The Urethane Vise Pads are designed to be custom fitted to your vise. It may be necessary to cut a portion of the urethane from the bottom side of each pad to widen the opening enough so that each pad will slip over the vise's channel slide. The Urethane pads should be fitted so that the v-grooves are in the center of the jaw and there is approximately 1/4" of the pad above the vise.

These pads were initially developed for holding wooden wood heads in the needed positions while doing a variety of repairs, including back screw removal, face and sole plate re-surfacing, cutting of score lines, installing insert screws, applying whipping, face filing, etc.

The Urethane Vise Pads are also a great all purpose pad that can protect classic and modern club heads and shafts when the club is to be secured in a vise*. Caution: Do not over tighten a golf club in a vise. Over tightening can cause damage to the golf club. These Urethane Vise Pads can not prevent damage to any part of a golf club. Care must always be taken when securing a golf club in a vise.

* When clamping a metal wood or wooden wood in the toe down position in a vise with the Urethane Vise Pads in place, be careful that the toe of the wood does not come in contact with the vise channel. This can cause damage to the finish on the toe of the club head.

Note: It is recommended that the Urethane Vise Pads be thoroughly cleaned before use with metal wood heads. An alternative would be to keep a second set of Urethane Vise Pads specifically for use with metal wood heads.

